GLite PRO Vario | Vario+ (module only)



GLite PRO Vario (module) listening communicator



GLite PRO Vario+ (module) Extended microphone version

GLite PRO Vario (module) has been developed as a step between our most advanced series gHost and our lowest Longlife modules. **Glite PRO Vario (module)** gives you the ability to control your device via SMS and its miniature size and **Knowles microphone** make it one of the most competitve devices available on the market. **Module requires an external battery!** Compatible with 180-220V devices and plugs.

TECHNICAL SPECIFICAITON

	Standby days	Callback days	In call hours	Micro-phone
GLite PRO module 7200	75.0	43.0	48.0	short
GLite PRO module 12000	125.0	71.4	80.0	short

*Maximum values tested

PASSWORD	THIS COMMANDFOR CHANGING THE PASSWORDFROMORIGINAL „123456" TO YOUR SPECIFY 6 DIGIT	123456lSPACEJP lSPACEl654321 lEXAM' tE 0 NEW PASSWffiDl YOO WILL RJ:CEIVF A SMS WITIl Tff NEW P\SSWORO: NEW PASSWORD:654321"
NUMBER FOR OUTGOING CALLS	THIS COMMAND SETS THE NUM-BER TO WHICH THE DEVICE CALLS OR SENDS SMS	123456lSPACEJNlSPACEl +420111222333
NUMBER FOR INCOMING CALLS	THESE COMMANDS SET THE NUM-BERS FROM WHICH YOU CAN CALL TO THE DEVICE(Up TO 3 DIFFERENT NUMBERSJ 11I12 I13	SEND SMS WITH ht:CONTROLLING COfi:QM_Y. EXAMA._E: 123456 lSPACLl l1l 12l13 123456lSP CEl1lSPACFJ +420111222333 123456lSP CEl2lSPACEJ +420444555666 123456lSPACE1l 3lSPACtl+420777888999
DEACTIVATION OF incoming CALL	THIS COMMAND YOU CAN TURN OFF THE PROTECTION OFRECEIVING CALLS FROM AUTHORIZED NUMBERS U1 I 121131	123456lSPACEHl lSPACEl 1l 0 H 1=Dt:VIIIWILL RECUVE \NY ttiMBER. H 0 =DEVICE WILLRECEIVE SET ttiMBER.
VOX SET	COMMAND SETS THE SENSTI IVITY OF DEVICE INTEGRATED DETECTOR AUTOMATIC SOUND DETECTION AND DEAD TIME	123456lSPACEJ T lSPACE0l 2lSPACEJ 50 FIRST W lf = NOILEVEL DO -10lMAXl SECOND \1Xlf = OORF PIR MQ[f 00 -90 MIN
MICROPHONE GAIN	THIS COMMAND ADJUSTS THE INNER AMPLIFIER	123456lSPACtlG lSPACE1l -7 1-5LEVEL Of AM-tiFitn 6 FOR SIENT ENVUi(]M:NT 7 FOR LIlJDER ENVFIONM:NT
LIGHT CONTROL	THIS COMMAND ADJUSTS THE LIGHT DETECTION ON/OFF	123456lSPACtlL lSPACE1l /0 1= ON / 0 = OFF
FACTORY RESET	THE DEVICE DEFAULTS TO FACTO-RY SETTING.COMMUNICATOR WILL SEND SMS WITH THE NEW CFACTORYJ SETTING	123456lSPACEJRESET